

3M[™] 7500 Series Half Mask

Cleaning and Inspection



- Inspect respirator for incorrectly fitted and/or damaged parts. Replace if necessary
- Inspect the exhalation valve and seat. Any damaged or deteriorated valves should be replaced

Monthly

- · Carry out all the 'Before Use' inspections
- Check:

Face Seal Straps and Head harness Valves

Create record of this monthly check

CORRECT LEVELS OF PROTECTION

After Use

- · Cleaning is recommended after each use
- Remove the gas/vapour and/or particulate filters
- Clean with 3M 105 wipe or by immersing in warm cleaning solution, water temperature not to exceed 50°C and scrub with a soft brush until clean
- · Rinse in fresh warm water
- Air dry in a non-contaminated atmosphere

Ordering Consumables, Repair Parts and Accessories

To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on Care and Maintenance of your 3M Reusable Respirators, please contact the helpline.

3M Health and Safety Helpine


0870 60 800 60 (UK) 1 800 320 500 (Ireland)

REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE

Occupational Health & **Environmental Safety Group** 3M United Kingdom PLC 3M Centre Cain Road Bracknell Berkshire RG12 8HT Helpline: 0870 60 800 60 www.3M.com/uk/ohes

Occupational Health & **Environmental Safety Group** 3M Ireland 3M House Adelphi Centre Upper Georges St. Dun Laoghaire Co. Dublin, Ireland Helpline: 1 800 320 500

Printed in the United Kingdom © 3M 2008. All rights reserved.



		3M Part Number
1	Head Harness	7581
2	Inhale Valve	7582
3	Exhale Valve	7583
4	Filter Holder	7586

